

miDock™ PORTFOLIO FOR STILETTO™ User's Guide



Introduction

The *miDock™ PORTFOLIO FOR STILETTO™* is a portable audio system designed specifically for Stiletto and other MP3 players.

The *miDock™ PORTFOLIO FOR STILETTO™* can operate via battery power or through an AC adapter, which will charge your Stiletto's battery while docked.

Note: Charging does not occur when operating the *miDock™ PORTFOLIO FOR STILETTO™* in battery mode.

The following information will help you get the most from your *miDock™ PORTFOLIO FOR STILETTO™*.

What's In The Box?

- o *miDock™ PORTFOLIO FOR STILETTO™* docking system
- o Carry bag
- o Adapter inserts for different STILETTO models
- o Extraction tool for changing adapters
- o 12V power adapter for AC operation

1 Setting Up Your *miDock™ PORTFOLIO FOR STILETTO™* AC & Battery Operation. Plug the adapter cable into the 12V DC power input jack at the back of your *miDock™ PORTFOLIO FOR STILETTO™*. Plug the AC power adapter into a 120V wall outlet. To enjoy your favorite music anywhere, anytime, install four (4) AA batteries in the battery compartment located on the bottom of the unit.

2 Use The Right Adapter For Your Stiletto. In the *miDock™ PORTFOLIO FOR STILETTO™* box, you will

find a pair of reversible adapters for different Stiletto models: SL10/100 and SL2. Using the diagram overleaf, select the side which fits your model and install accordingly.

3 Dock Your Stiletto. With the power switch Off, place your Stiletto into the docking cradle and push down gently, but firmly to ensure that the docking connector is fully seated and your Stiletto is securely held in the cradle.

Note: If using the *miDock™ PORTFOLIO FOR STILETTO™* in battery mode, turn your Stiletto on first before docking to help conserve battery life.

4 Turn It On, Turn It Up! Press the power switch on the front panel. Volume controls are on the right side of the system.

Notes

If there is no audio output when operating on battery power the *miDock™ PORTFOLIO FOR STILETTO™* automatically turns off after 10 minutes to conserve battery life.

To use a music source other than Stiletto, use an interconnect audio cable with a 3.5 mm stereo plug. Your *miDock™ PORTFOLIO FOR STILETTO™* auxiliary input is located on the rear of the unit.

Caution—Listen To This!

Be careful to set the volume on the MP3 player at a safe level before playing music through your *miDock™ PORTFOLIO FOR STILETTO™*. You may need to adjust both the *miDock™ PORTFOLIO FOR STILETTO™* and MP3 player volume controls to get the best result.

Limited One Year Consumer Warranty


Directed Electronics (herein "DIRECTED") promises to the original purchaser, to repair or replace this product (herein "unit") with a new or refurbished unit should it prove to be defective in workmanship or material under normal use, for a period of one-year from the date of purchase from the dealer as indicated by the date code marking of the unit. During this one-year period, there will be no charge for this repair or replacement PROVIDED the unit is returned to DIRECTED, shipping pre-paid. This warranty is non-transferable and does not apply to any unit that has been modified or used in a manner contrary to its intended purpose, and does not cover damage to the unit caused by installation or removal of the unit. This warranty is void if the product has been damaged by accident or unreasonable use, neglect, improper service or other causes not arising out of defects in materials or construction. Units which are found to be damaged by abuse resulting in thermally damaged voice coils are not covered by this warranty but may be replaced at the absolute/sole discretion of DIRECTED. This warranty does not cover the elimination of externally generated static or noise, or the correction of antenna problems or weak reception, damage to speakers, accessories, electrical systems, cosmetic damage, or damage due to negligence, misuse, failure to follow operating instructions, accidental spills or customer applied cleaners, damage due to environmental causes such as lightning, extreme temperatures, damage due to accidents, fire, theft, damage due to improper connection to equipment of another manufacturer, modification of existing equipment, or any unit which has been tampered for any reason. ALL WARRANTIES, INCLUDING BUT NOT LIMITED TO EXPRESS WARRANTY, IMPLIED WARRANTY, WARRANTY OF MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE, AND WARRANTY OF NON-INFRINGEMENT OF INTELLECTUAL PROPERTY ARE EXPRESSLY EXCLUDED TO THE MAXIMUM EXTENT ALLOWED BY LAW, AND DIRECTED NEITHER ASSUMES NOR AUTHORIZES ANY PERSON TO ASSUME FOR IT ANY LIABILITY IN CONNECTION WITH THE SALE OF THE PRODUCT. DIRECTED HAS ABSOLUTELY NO LIABILITY FOR ANY AND ALL ACTS OF THIRD PARTIES INCLUDING ITS AUTHORIZED DEALERS OR INSTALLERS. IN NO EVENT WILL DIRECTED BE LIABLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFITS) AND IN NO EVENT, SHALL DIRECTED'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY DEALER FOR THE PRODUCT. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Unit must be returned to DIRECTED, postage prepaid, with bill of sale or other dated proof of purchase bearing the following information: consumer's name, telephone number, and address, authorized dealer's name and address, and product description. Note: This warranty does not cover labor costs for the removal and reinstallation of the unit. This warranty is only valid for sale of product within the United States of America. Products or units sold outside of the United States are sold As-Is. IN ORDER FOR THIS WARRANTY TO BE VALID, YOUR UNIT MUST BE SHIPPED WITH PROOF OF PURCHASE FROM AN AUTHORIZED DIRECTED DEALER. BY PURCHASING THIS PRODUCT, THE CONSUMER AGREES AND CONSENTS THAT ALL DISPUTES BETWEEN THE CONSUMER AND DIRECTED SHALL BE RESOLVED IN ACCORDANCE WITH CALIFORNIA LAWS IN SAN DIEGO COUNTY, CALIFORNIA.

9200018 2007-09

miDock™ PORTFOLIO™
FOR STILETTO™

ADAPTER USAGE


A pair of adapters for different Stiletto models and an extraction tool are included with the *miDock™ PORTFOLIO FOR STILETTO™*. Choose the correct adapter side to fit your model. Each adapter is labeled either L or R to indicate cradle sides left or right. Insert into the sidewalls of cradle first before docking your system. Details are shown below.



Adapters are reversible for different Stiletto models, side shown above (wide, thin protrusion) is for Stiletto 10/100, opposite side (short, thick protrusion) is for Stiletto 2.

To remove or reverse adapters use the provided extraction tool, hook into the adapter aperture, turn 90° and pull adapter outward from cradle sidewall.

TOP VIEW of ADAPTERS



For product support contact Directed Electronics at 1-800-753-0800. For more information on this and other SIRIUS accessories please visit us at www.directedsirius.com.

SIRIUS & the SIRIUS dog logo are registered trademarks of SIRIUS Satellite Radio Inc.

PORTFOLIO miDock™ POUR STILETTO™

Guide de l'utilisateur



Introduction

Le *PORTFOLIO miDock™ POUR STILETTO™* est un système audio portatif conçu spécialement pour le iPod et autres lecteurs MP3. Il fonctionne sur piles ou avec un adaptateur CA. Votre *PORTFOLIO miDock™ POUR STILETTO™* charge aussi la pile de votre iPod lorsqu'il est raccordé et que l'adaptateur CA est connecté. L'information suivante vous aidera à profiter au maximum de votre *PORTFOLIO miDock™ POUR STILETTO™*.

Note: Le *PORTFOLIO miDock™ POUR STILETTO™* ne se charge pas quand il fonctionne sur piles.

Que contient la boîte?

- o La station d'accueil du *PORTFOLIO miDock™ POUR STILETTO™*
- o L'étui de transport
- o Des inserts d'adaptateurs pour différents modèles STILETTO
- o Un outil d'extraction pour changer d'adaptateur
- o Un adaptateur 12V pour fonctionnement CA

1 Préparez votre *PORTFOLIO miDock™ POUR STILETTO™* Fonctionnement CA et sur piles. Branchez le câble de l'adaptateur dans l'entrée 12V CC à l'arrière de votre *PORTFOLIO miDock™ POUR STILETTO™*. Branchez l'adaptateur CA dans une prise murale 120V. Pour profiter de votre musique favorite en tout temps et en tout lieu, placez quatre (4) piles AA dans le compartiment à piles situé sous l'unité.

2 Choisissez le bon insert d'adaptateur pour votre Stiletto. Vous trouverez dans la boîte du *PORTFOLIO miDock™ POUR STILETTO™* une paire d'adaptateurs réversibles pour des modèles Stiletto différents:

SL10/100 et SL2 Utilisez le guide des adaptateurs inclus pour choisir et installer celui qui convient à votre iPod.

3 Connectez votre Stiletto. Placez votre Stiletto éteint dans sa station d'accueil. Pressez doucement mais fermement pour vous assurer que le connecteur d'accueil est bien engagé et que votre Stiletto est bien enfoncé dans son socle.

Note: Quand vous utilisez le *PORTFOLIO miDock™ POUR STILETTO™* sur piles, allumez le Stiletto avant de le connecter pour économiser les piles.

4 Allumez et réglez le volume! Pressez le commutateur de mise en marche sur le panneau avant. Les commandes de volume sont sur le côté droit du système.

Notes

En l'absence de sortie audio et en fonctionnement sur piles, le *PORTFOLIO miDock™ POUR STILETTO™* s'éteint automatiquement après 10 minutes pour économiser les piles.

Pour utiliser une autre source musicale qu'un Stiletto, utilisez un câble de connexion audio avec une prise stéréo 3,5 mm. L'entrée auxiliaire de votre *PORTFOLIO miDock™ POUR STILETTO™* se trouve à l'arrière de l'unité.

Attention — Écoutez bien ceci!


Assurez-vous de régler le volume de votre lecteur MP3 à un niveau sécuritaire avant de faire jouer de la musique dans votre *PORTFOLIO miDock™ POUR STILETTO™*. Il faudra peut-être ajuster le volume du *PORTFOLIO miDock™ POUR STILETTO™* et du lecteur MP3 pour obtenir un niveau satisfaisant.

Garantie limitée d'un an du consommateur

Directed Electronics (ci-après appelée "DIRECTED") s'engage envers l'acheteur original à remplacer ce produit s'il s'avère défectueux en pièces ou main d'œuvre à la suite d'une utilisation normale et pour une durée d'un an à partir de la date d'achat du distributeur dont fait foi le code de date du produit. Durant cette période d'un an, DIRECTED remplacera le produit gratuitement s'il est retourné à DIRECTED, port payé. Cette garantie n'est pas transférable et ne s'applique pas aux produits modifiés ou utilisés de manière contraire à leur utilisation normale, et ne couvre pas les dommages causés par son installation ou son extraction. Cette garantie est nulle si le produit a été endommagé par accident ou utilisation déraisonnable, négligence, maintenance inadéquate ou toute autre raison non reliée à un défaut de pièces ou main d'œuvre. Les unités endommagées par un usage abusif ayant causé un endommagement thermique aux bobines acoustiques ne sont pas couvertes, mais pourront être remplacées à la discrétion exclusive et absolue de DIRECTED. TOUTES GARANTIES, INCLUANT MAIS NON LIMITÉE À TOUTE GARANTIE EXPRESSE OU TACITE, GARANTIE DE QUALITÉ MARCHANDE, D'APTITUDE À UN USAGE PARTICULIER OU DE NON-VIOLATION DE LA PROPRIÉTÉ INTELLECTUELLE, SONT EXPRESSÉMENT EXCLUES DANS TOUTE LA MESURE AUTORISÉE PAR LA LOI, ET DIRECTED N'ASSUME NI N'AUTORISE QUICONQUE À ASSUMER UNE QUELCONQUE RESPONSABILITÉ RELIÉE À LA VENTE DE CE PRODUIT. DIRECTED N'ASSUME ABSOLUMENT AUCUNE RESPONSABILITÉ QUANT À TOUTE ACTION ENTREPRISE PAR DES TIERS PARTIES, INCLUANT SES DISTRIBUTEURS OU INSTALLATEURS AUTORISÉS. EN AUCUNE MANIÈRE DIRECTED NE POURRA ÊTRE TENUE RESPONSABLE DE DOMMAGES OU PERTES DE PROFIT ACCESSOIRES, SPÉCIAUX OU CONSÉCUTIFS. EN AUCUN CAS LA RESPONSABILITÉ DE DIRECTED N'EXCÉDERA LE PRIX PAYÉ PAR L'ACHETEUR. Certains états ne permettent pas l'exclusion ou la limitation des dommages accessoires ou consécutifs, cette limitation ou exclusion peut donc ne pas s'appliquer à vous. Le produit doit être retourné à DIRECTED, port payé, avec une facture ou autre preuve d'achat datée comportant les renseignements suivants: nom du consommateur, numéro de téléphone et adresse, nom et adresse du distributeur autorisé, et description du produit. Note: Cette garantie ne couvre pas les frais de main d'œuvre pour la désinstallation et la réinstallation du dispositif. POUR QUE CETTE GARANTIE SOIT VALIDE, LE PRODUIT DOIT ÊTRE EXPÉDIÉ AVEC UNE PREUVE D'ACHAT D'UN DISTRIBUTEUR AUTORISÉ DIRECTED. EN ACHETANT CE PRODUIT, LE CONSOMMATEUR ACCEPTE ET CONSENTE À CE QUE TOUT LITIGE ENTRE LE CONSOMMATEUR ET DIRECTED SOIT RÉSOLU EN CONFORMITÉ AVEC LES LOIS DE L'ÉTAT DE CALIFORNIE DU COMTÉ DE SAN DIEGO, EN CALIFORNIE.

UTILISATION DES ADAPTATEURS



Une paire d'adaptateurs pour différents modèles Stiletto et un outil d'extraction sont inclus avec le *PORTFOLIO miDock™ POUR STILETTO™*. Choisissez le bon côté d'adaptateur pour votre modèle. Chacun est marqué L ou R pour gauche et droite respectivement pour indiquer le côté gauche ou droit du socle. Insérez dans les parois latérales du socle avant de connecter votre système. Détails ci-dessous.



L'insert est réversible selon les modèles Stiletto. Le côté utilisé pour le Stiletto 10/100 (protubérance longue et mince) est illustré. L'autre côté (protubérance courte et épaisse) pour le Stiletto 2.

Pour ôter ou inverser les adaptateurs, utilisez l'outil d'extraction fourni, accrochez-le dans l'ouverture de l'adaptateur, tournez à 90° et tirez sur l'adaptateur pour le faire sortir de la paroi latérale du socle.

ADAPTATEURS VUS DE DESSUS



Pour le service à la clientèle, contactez Directed Electronics au 1 800 753-0800. Pour plus de renseignements sur ces accessoires et autres produits SIRIUS, visitez-nous à www.directedsirius.com.

SIRIUS et le logo SIRIUS sont des marques déposées de SIRIUS Satellite Radio Inc.